



Instructies

Reserveer online: Zelfs tot 10 minuten voor vertrek. Heb je een bevestiging ontvangen dan kan je de onderstaande stappen doorlopen bij aankomst op de locatie.

Sleutel: Het mobiele nummer dat wij van je hebben ontvangen bij de reservering is de sleutel van de boot!

1 Doe de plug in de zelflozer

Je vind deze links- en rechtsachter op de vloer van de sloep. Draai/knik ze een kwartslag en ze zitten vast. Als ze er al in zitten is dat ook prima.

2 Boot aanzetten

SMS "Sloep# aan" naar +31635250034 # is het sloepnummer

Voorbeeld: heb je sloep2 gehuurd dan typ je 'sloep2 aan'. Na ongeveer 1 minuut is de boot actief (dit is ook te horen aan een 'klik' geluid van het ontgrendelen. Je ontvangt een bevestiging SMS.

3 Haal de stekker uit het stopcontact

Deze zit vast aan de kade. Leg de stekker in het bankje van de sloep. Als de stekker er al uit is is dat geen probleem. (de sloep kan 10-12 uur varen zonder op te laden)

4 Gaan varen

Druk de ronde knop onder de gashendel in en maak de boot los. Je kan nu gaan varen door de gashendel vooruit danwel achteruit te bewegen. Wijst de hendel omhoog dan wordt er geen gas gegeven. let op: de motor is stil dus je hoort het bijna niet.

Geniet van je vaartocht!

5 Klaar met varen?

Leg de boot op tijd aan, meld eventuele schade altijd telefonisch. Om de huurperiode (en betaling) te stoppen dien je het volgende te doen: **SMS "Sloep# uit" naar ons nummer +31635250034** je ontvangt een bevestiging sms als alles goed is gegaan.

Zorg dat de stekker weer in het stopcontact zit, haal de pluggen eruit en druk de knop onder de gashendel in om de sloep uit te zetten.

Vragen? Bel ons gerust op 085-4019555



Getting started

Book online: This is possible up to 10 minutes before departure. Once your booking is confirmed follow the the steps below at your arrival on location.

Key: Your mobile number registrated at the time of reservation is the key to unlock the boat!

1 Close the draining plugs

The 2 plugs are located on the bottom/floor of the boat on the left- and rightside. Put the plugs in and turn the handle downwards (the handle is now horizontal).

2 Boat activation

Text message "Sloep# aan" to +31635250034 # is the boatnumber

Example: if you reserved sloep2, type 'sloep2 aan' en text this to the number above. The boat will be active within one minute! You will receive a confirmation text message.

3 Unplug the electricity plug

It's connected to the dock. Put the cable in the boat. If the cable is already plugged out it's no problem. (boat can operate 10-12hrs without charging)

4 Drive off

Press the round button at the right side of the steering wheel. And make sure all lines are untied. Now use the gas handle forward or backward to operate the boat. The upright position is neutral. Note: the motor is silent, so you don't hear it.

Enjoy the trip!

5 Finished?

Be back in time, if there is damage call us to report. To stop your rental (and payment) you can simply text message us again. Do the following:

Text message "Sloep# uit" to our number +31635250034

you will receive a confirmation message.

Make sure the electricity plug is plugged in again and the draining plugs are plugged out. Press the round button again to switch the boat off.

Questions? Call us at 085-4019555

